

Mounting and Operating Manual

Electrical Small Component Gripper WSG 25

Firmware Version: 4.0.2

Hardware Version: 0

February 2016



www.weiss-robotics.com

Table of contents

1	Introduction	3
2	About this manual	4
2.1	Applicable documents	4
2.2	Target audience.....	4
2.3	Notation and symbols.....	4
3	Basic safety notes	5
3.1	Intended use	5
3.2	Environmental and operating conditions.....	5
3.3	Product safety	5
3.3.1	Protective equipment.....	5
3.3.2	Constructional changes, attachments, or modifications.....	6
3.3.3	Special standards.....	6
3.4	Personnel qualification	6
3.5	Safety Considerations	6
3.6	Notes on particular risks	6
4	Warranty	7
5	Scope of delivery	7
6	Technical Data	8
6.1	Outer dimensions	8
6.2	Nominal mechanical data	8
6.2.1	Mechanical Finger Load.....	10
6.2.2	Gripping force.....	11
6.3	Nominal electrical data	13
6.4	Interfaces and connections	14
6.4.1	Fuse.....	14
6.4.2	Power supply and Ethernet	14
6.5	Name plate	15
7	Installation	15
7.1	Installation instructions	15
7.2	Mechanical connection	16
7.3	Installation of the fingers.....	16
7.4	Initial Startup	17
7.5	Changing the IP address and using DHCP	19

8	Operation	20
8.1	Operating software	20
8.2	Integrated memory	20
8.3	Boot process	20
8.4	Display of operating state	21
8.5	Status word and gripper state	22
8.5.1	Status word.....	22
8.5.2	Gripper state.....	23
8.6	Homing the module.....	24
8.7	Gripping, part detection and grip monitoring	25
8.8	Software limit switch.....	26
8.9	Fast Stops requiring acknowledgment.....	27
8.10	Log memory	28
8.11	Thermal monitor	28
8.12	Monitoring the drive current	29
8.13	Monitoring the supply voltage	29
8.14	Configuration and diagnosis via the web interface.....	30
8.14.1	Access restrictions for the web user interface	31
8.15	Command interface	32
8.16	Scripting (optional)	32
8.17	Resetting the configuration.....	33
8.18	Implementing the gripping process	33
9	Maintenance and cleaning	35
10	Troubleshooting	36
10.1	The gripper jaws don't move.....	36
10.2	Module stops abruptly.....	36
10.3	No connection to the web interface	37
11	EC Declaration of Incorporation	38

1 Introduction

The WSG 25 is an electrical 2-Finger Small Component Gripper. It has an integrated control unit supporting the Interfaces: Ethernet TCP/IP and Modbus/TCP (optional). Fig. 1 shows the components and connectors of the module. The configuration of the module is done via a Web-Interface supporting almost every common web browser.




Fig. 1: Components and connectors of the WSG 25

2 About this manual

This instruction is an integral part of the product and contains important information for a safe and proper assembly, commissioning, operation, maintenance and helps for an easier trouble shooting.

Before using the product, read and note the instruction, especially the chapter 3 "Basic safety notes". This manual is exclusively valid for the gripper type WSG 25.

2.1 Applicable documents

For more detailed information about the operation of this module, please see the following documents which are available both in PDF format on the accompanying CD as well as via the WSG web interface:

- **WSG Command Set Reference Manual** - Description of the binary command protocol (TCP/IP)
- **WSG GCL Reference Manual** – Description of the text based command protocol (TCP/IP)
- **WSG Fieldbus Interface Manual** – Description of the fieldbus interface (Modbus/TCP)
- **WSG Scripting Reference Manual** - Description of the optional script interpreter for the gripper control system

Please find additional information about the warranty in our general terms and conditions, available online at www.weiss-robotics.com.

2.2 Target audience

Target audience for these instructions are plant manufacturers and operators who keep this and other documents supplied to the personnel at all times and also ask to read and observe particularly the safety instructions and warnings.

In addition, it is aimed at professionals and technicians who read this manual, while they should particularly observe the safety and warning notes at all times.

2.3 Notation and symbols

For better clarity, the following symbols are used in this manual:

	Functional or safety-related information. Failure to comply may jeopardize the safety of personnel and equipment, damage the device or impair the function of the device.
	Additional information for a better understanding of the facts described.



Reference to further information.

3 Basic safety notes

3.1 Intended use

- The module was designed to grip and to temporarily and securely hold work pieces and objects.
- The module is intended for installation in a machine/system. The requirements of the applicable guidelines must be observed and complied with.
- The module may be used only in the context of its defined application parameters.

To use this unit as intended, it is also essential to observe the technical data and installation and operation notes in this manual and to comply with the maintenance intervals.

3.2 Environmental and operating conditions

- The module may only be used within its defined application parameters.
- It must be ensured that the module and the top jaws are sufficiently dimensioned according to the use case.
- It must be ensured that the environment is clean and the ambient temperature corresponds to the specifications catalogue. Please observe the maintenance instructions (see chapter 9).
- It must be ensured that the environment is free from splash and vapours as well as from abrasion or process dust. Excepted are modules that are specifically designed for dirty environments.

3.3 Product safety

Dangers arise from the module, if e.g.:

- The module is not used in accordance with its intended purpose.
- The module is not installed or maintained properly.
- The safety and installation notes are not observed.

Avoid any manner of working that may interfere with the function and operational safety of the module.

Wear protective equipment.

3.3.1 Protective equipment



Provide protective equipment per EC Machine Directive

3.3.2 Constructional changes, attachments, or modifications

Additional drill holes, threads, or attachments that are not offered as accessories by Weiss Robotics may be attached only with permission of Weiss Robotics.

3.3.3 Special standards

The following standards are met:

- Fast transients on supply and I/O lines (burst) to IEC / EN 61000-4-4
- FH power supply to IEC/EN 61000-4-6
- HF radiation according to IEC/EN 61000-4-3
- Emissions according to EN 55011:2009 Class A (corresponds to EN 61000-6-4:2007)
- Power frequency magnetic field according to EN 61000-4-8

3.4 Personnel qualification

The assembly, initial commissioning, maintenance, and repair of the module may be performed only by trained specialist personnel. Every person called upon by the operator to work on the module must have read and understood the complete assembly and operating manual especially the chapter 3 "Basic safety notes". This applies particularly to personnel only used occasionally, such as maintenance personnel.

3.5 Safety Considerations

 **Avoid any operation that affects the function and reliability of the module.**

 **Observe applicable on site safety and accident prevention regulations.**

3.6 Notes on particular risks

Generally valid:

Risk of injury from objects falling and being ejected

 **The danger zone must be surrounded by a safety fence during operation.**

Risk of injury due to squeezing and bumping during movement of the gripper jaws and breaking or loosening of the gripper fingers

 **While disassembling uncontrollable moves of parts of the gripper possible!**

-  Do not move parts by hand when the energy supply is connected.
-  Do not reach into the open mechanism or the movement area of the module.
-  Remove the energy supplies before installation, modification, maintenance, or adjustment work.
-  Make sure, that no residual energy remains in the system.
-  Perform maintenance, modifications, and additions outside the danger zone.
-  For all work, secure the unit against accidental operation.
-  Take a precautionary approach by maintenance and disassembly.
-  Only special trained staff should disassemble the module.

4 Warranty

The warranty is valid for 24 months from the delivery date to the production facility under the following conditions:

- Intended use in 1-shift operation
- Observe the mandatory maintenance and lubrication intervals.
- Observe the environmental and operating conditions.

Parts touching the work piece and wearing parts are not part of the warranty.

The module is considered defective if its basic function “gripping” is no longer given.

5 Scope of delivery

The scope of delivery includes:

- WSG 25-064 servo-electric 2-finger parallel gripper
- Operating manual
- CD with documentation and firmware

The following accessories that are required for the module must be ordered separately:


- Power supply and Ethernet cable 5 m, M8 female connector, 6-pole, straight to RJ-45 and open wire for power supply for WSG 25, item no. AL-ETH-6P-5M
- Software Add-On „Lua scripting“, item no. OPT-WSG25-SCR



Please order accessories separately. More accessories can be found on our web site www.weiss-robotics.com.

6 Technical Data

6.1 Outer dimensions



Jaws are displayed in open position.




Fig. 2: Outer dimensions

6.2 Nominal mechanical data



Exceeding the specified nominal data can damage the module. If in doubt, please discuss your application with our technical sales department.

Mechanical operating data	Unit	Min.	Typical	Max.	Remark
Stroke per finger	mm		32		
Nominal gripping force	N		20		
Minimum gripping force	N			5	Gripping speed 5 mm/s, finger length 40 mm, steel on steel
Maximum gripping force	N	20			Gripping speed 50 mm/s, finger length 40 mm, steel on steel
Weight	g		320		
Workpiece weight	g			200	
Finger length	mm			50	at nominal force, see Fig. 3
Mass per finger	g			22	
Tightness	IP		40		DIN EN 60529
Ambient temperature	°C	5		50	
Air humidity	%	0		90	Non condensing
Repeatability	mm		±0.03		3σ-deviation
Gripping speed	mm/s	5		300	
Acceleration	mm/s ²	100		5000	




Fig. 3: Determining the clamping height




Fig. 4: Typical acceleration (5000 mm/s²) at gripping force of 20 N and finger weight of 2x 22 g

6.2.1 Mechanical Finger Load

The following table shows the maximum load of the finger. The specified load may be applied simultaneously and in addition to the gripping force.

Mechanical Load	Unit	Min.	Typ.	Max.	Remark
F_z	N			30	
M_x	Nm			0.55	
M_y	Nm			0.55	
M_z	Nm			0.3	




Figure 1: Mechanical finger load

6.2.2 Gripping force

The gripping force is defined as the effective force acting between the fingers multiplied by the number of fingers in contact with the part to be grasped. The gripping force is calibrated during the manufacturing process. The actual gripping force depends on gripping speed, finger length and temperature. Fig. 5 shows the recommended gripping speed according to the desired gripping force.




Fig. 5: Recommended gripping speed (steel on steel, finger length 40 mm)

△ The diagram above is considered as a recommendation. If in doubt, please try out and measure the actual force for your application.




Fig. 6: Gripping force dependent on finger length (example)

Definition of the nominal gripping force

To determine the nominal gripping force, the module was non-positively mounted to an aluminum plate, see Fig.. The plate itself was thermally insulated from the underlying surface. With an ambient temperature of 22° C the module can hold with the nominal gripping force for at least 5 hours.




Fig. 7: Arrangement for ascertaining the nominal gripping force

⚠ For high gripping forces or long holding cycles, make sure that heat is well dissipated via the screw contact surface. Damage to the module is possible!

6.3 Nominal electrical data

⚠ Exceeding the specified nominal data can damage the module. If in doubt, please discuss your application with our technical sales department.

Parameter	Unit	Min.	Typical	Max.	Remark
Clamping voltage	V DC	22	24	28	
Current drawn when idle	A		0.1		
Current drawn when holding	A		0.40		Gripping force = 20 N
Controller		integrated			
Field bus interface		Ethernet TCP/IP, Ethernet UDP/IP			
Configuration interface		web based			

6.4 Interfaces and connections

The module has an Ethernet-interface for control. Selection of the used protocol and configuration of the IP-Adress is done via the web-interface (see. chapter 7.5).

6.4.1 Fuse

The module has an integrated fuse to protect against short circuits and incorrect polarity.

 **To have the fuse changed, please contact an authorized sales partner.**

6.4.2 Power supply and Ethernet

Power is supplied via a 6-way M8 connector on the modules housing, which also carries the Ethernet interface. Ethernet can be used for commands as well as for configuration and diagnosis via the web server (cf. chapter 8). The Ethernet interface is electrically isolated. Fig. shows the pin assignments.




Fig.8: Terminal assignment of the power supply and Ethernet connector (view on plug)

Requirement for the power supply:

- Power supply: 24 V DC $\pm 10\%$
- Ripple < 150mV_{pp}
- Available output current: at least 1.5 A

The following cable from Weiss Robotics is suitable to connect the power supply and Ethernet interface:

- Type: AL-ETHP-6P-5M (M8 straight to RJ-45, cable length: 5 m)

Commands are sent to the module via TCP connections, using the TCP or UDP protocol. For further information, please see the “WSG Command Set Reference Manual” (on the accompanying CD or can be called up via the web interface).

The module currently also supports the following network services: DHCP (dynamic IP addresses), SNTP (network time), HTTP (web user interface), DNS (resolution of host names).

Interface specification

Parameter	Unit	Min.	Typical	Max.	Remark
Transmission standard		IEEE 802.3			
Communication standard		TCP/IP (v4), UDP/IP (v4)			
Transmission speed	MBit/s	10; 100			Auto-negotiated
Transmission type		Half duplex			
Auto-MDIX		yes			

6.5 Name plate

The name plate is on the narrow side of the module above the connector.



Fig. 9: Name plate

7 Installation

7.1 Installation instructions

-  Risk of injury because of electrical energy!
-  Warning: Risk of injury when the machine/system moves unexpectedly!
-  Remove energy supplies during all maintenance work and adjustments.

7.2 Mechanical connection

The threads which can be used to mount the module and the centering holes are shown in Fig.. The module has M3 threads for fixing on the rear of its housing as well as 4 mm centering holes. Additionally the module can be mounted at its side by two through-holes.

When in holding mode, the module constantly adjusts the gripping force, to ensure a constant gripping force. The surfaces which are screwed together must be capable of dissipating the resulting heat.

-  **Risk of burns from hot surfaces!**
-  **Please ensure that the thermal coupling is good, especially if the module is to apply high gripping forces over longer periods of time. There is a risk of overheating!**
-  **Prevent exposure to external sources of heat, such as from your robot's pan-tilt unit, as this can reduce the module's performance. Poor dissipation of heat or exposure to additional heat will require the gripping force to be reduced.**
-  **To ensure fault-free operation and to minimize the radiation of electromagnetic interference (EMC) the module's housing must be properly earthed.**




Fig.10: Mechanical connection

-  **Do not exceed maximum torque: M3 threads = 0.8 Nm MAX**

7.3 Installation of the fingers

To install fingers, please use two Screws of the size M3 each. The lower end of the screw mustn't reach out of the base jaw to prevent damage to the module's housing. Pins can be used to center the fingers, if required.




Fig. 11: Installation of the fingers

⚠ Do not exceed maximum torque: M3 threads = 1.0 Nm MAX

7.4 Initial Startup

When starting up the module for the first time, please follow the steps below:

1. Using the Ethernet/Power cable, connect the module to the existing Ethernet network of alternatively to the network card in your PC or laptop.

⚠ The module's IP address is factory-set to a static value of 192.168.1.20. Should you wish to operate several modules in the same network and/or if this address is already in use, then you will have to change the module's IP address accordingly (e.g. set the 2nd module's IP address to 192.168.1.21). To do that, first connect the module directly to your computer's network connection, to avoid address conflicts in the network. For more information about changing the IP address, please see chapter 7.5. To directly operate the module on your computer's network connection, you may have to alter your computer's network configuration. If in doubt, contact your system administrator.

2. Connect your module with the power supply (24 V, 1,5 A).

3. The module will now start up. The indicator for the operating state will light up blue and after about 5 seconds it will start flashing quickly blue. This signals that the module is booting. After about 15 seconds the indicator will slowly flash white. The module is ready for use.
4. On your computer, open the Internet browser and enter the address <http://192.168.1.20>.
5. You will be presented with the module's configuration interface (Fig.)
6. From the menu, select the "Motion → Manual Control" option and click on the "Home" button (Fig.). The module will now zero itself.




Fig. 12: The starting page of the web-based interface

7. Once the homing sequence has been finished, for test purposes, you can move the module via the web interface. For this, select the movement parameters about the adjuster and then click on the "Move" button.

 Important: The module must have been zeroed to be able to execute movement commands.

8. Other steps which you should take during the commissioning:

9. Call up the “Diagnostics → System State” page, to check the module’s supply voltage.
10. On the “Settings → Command Interface” page, select the protocol on which your module is to be operated.
11. If necessary, on the “Settings → Motion Configuration” page enable automatic homing during startup („Homing on Startup”).
12. On the “Settings → System” page, create a user with corresponding rights and activate the web interface’s security function, to prevent changes to your setting by unauthorized persons.




Fig. 13: “Manual Control” configuration page

7.5 Changing the IP address and using DHCP

To change the module’s IP address, in the web interface, select the “Settings → Network” option menu. Adjust the IP address, subnet masks and any gateway or DNS server addresses for your local network and confirm the changes by clicking on the “Apply” button.

⚠ After changing the network configuration you will have to restart the module.

To use addresses dynamically assigned via DHCP, check the corresponding box. In this case the module will automatically take its network configuration from a DHCP server.

 Please note that if you use DHCP to dynamically allocate IP addresses, there is no integrated way of finding out what IP address has been allocated. This is why the DHCP server should be configured so that the module is issued with an IP address which is known in advance.

 Please contact your network administrator for more information.

8 Operation

8.1 Operating software

The software needed to operate the module is already installed in the unit.

 To guarantee proper operation, the latest version of firmware should always be installed in the module.

 The latest firmware can be downloaded free of charge under www.weiss-robotics.de. The module has to be registered to do this.

8.2 Integrated memory

The module's gripper control has an integrated non-volatile storage. The storage cannot be exchanged by the user.

The storage holds the following data:

- The software needed to operate the module
- Configuration data
- Documentation and software tools (can be accessed via the web interface)
- Scripts (only if the optional software package OPT-WSG25-SCR is installed).

 With the optional software package OPT-WSG25-SCR user-specific data and scripts can be saved on the non-volatile storage. The storage has a capacity of 4 GB.

8.3 Boot process

The module has a boot loader, which loads and runs the unit's software from the internal storage when the unit is powered up. The indicator for the operating state will light up blue during this. If there is an error, the indicator will light up red for 5 seconds. After that the boot loader will automatically be restarted. This will continue until firmware can be loaded correctly.

8.4 Display of operating state

On the side, the module has a multi-colored indicator for the operating state (Fig.). The current operating state is shown here by both the color of the indicator as well as by the flash rate.




Fig. 14: Display of operating state

The following operating states are indicated:

State	Display
Loading the operating software The module loads the firmware and gets ready to start	Blue, constantly on
There was an error loading the operating software The boot process will automatically be restarted	Red for about 5 seconds, then blue again
The boot process for the operating software The operating software will be started and the control system will be configured.	Blue, flashing
Wait state The module is ready for operation and is waiting for a command.	White, slowly pulsating
Busy The module is in the initialization phase or is currently executing a command	White, quickly pulsating
Executing a script A script is being executed by the control system. Only with optional OPT-WSG25-SCR.	Green, quickly pulsating
Warning One or more parameters have reached warning limits. Please check the system's status via its web interface.	Yellow, quickly pulsating
Command received with no errors The module has received an error-free command	Green, pulses once
Error carrying out a command An error has occurred while receiving or executing a command.	Red, pulses once

<p>Critical fault</p> <p>An error has occurred (e.g. excess temperature, loss of communications, etc.). This error must be acknowledged before the module can process new commands to move.</p>	Red, pulses quickly
<p>Critical software fault</p> <p>A serious error has occurred and the execution of the software in the unit has been stopped. The module will restart after a short time.</p>	Red, flash code 2x short, long pause


8.5 Status word and gripper state

The module's current state can be called up at any time via the status word and the gripper state.

8.5.1 Status word

The current state of the gripper is summarized in the so-called status word. This can be read out via the command interface (using the command: Get System State, 40h), via the web interface or via a script (using the command: Read System State flags, gripper.state()). Fig. shows the display of the status word via the side bar in the web interface. The status word includes both pure status messages (e.g. zeroed, execution of script, etc.) as well as warnings and errors (e.g. temperature warning, power failure, etc.).

 You will find the documentation for the status word in the "WSG Command Set Reference Manual"



The screenshot shows the 'WSG 25 Control Panel' web interface. The main content area displays 'System Information' with a table of device details and an image of the gripper. A sidebar on the right contains three sections: 'Gripper' showing state (Idle), position (32.0 mm), speed (0.0 mm/s), and force (0.0 N); 'Fast Stop' with 'Stop' and 'Ack' buttons; and 'System State' with a list of status flags. The 'System State' list includes 'Referenced', 'Moving', 'Blocked Minus', 'Blocked Plus', 'Soft Limit Minus', 'Soft Limit Plus', 'Axis stopped', 'Target Pos reached', 'Force Control Mode', 'Fast Stop', 'Temperature Warning', 'Temperature Fault', 'Power Fault', 'Current Fault', 'Finger Fault', 'Command Failure', 'Script is running', and 'Script Failure'.

System Information	Value
System Type	WSG 25
Hardware Revision	0
Serial Number	00000001
Service Tag	(not set)
Ethernet Physical Address	00-A1-B0-0B-B6-48
Firmware Version	2.6.0
Custom Device Tag	

Gripper	Value
State	Idle
Position	32.0 mm
Speed	0.0 mm/s
Force	0.0 N

System State	Status
Referenced	Selected
Moving	Not Selected
Blocked Minus	Not Selected
Blocked Plus	Not Selected
Soft Limit Minus	Not Selected
Soft Limit Plus	Not Selected
Axis stopped	Not Selected
Target Pos reached	Selected
Force Control Mode	Not Selected
Fast Stop	Not Selected
Temperature Warning	Not Selected
Temperature Fault	Not Selected
Power Fault	Not Selected
Current Fault	Not Selected
Finger Fault	Not Selected
Command Failure	Not Selected
Script is running	Not Selected
Script Failure	Not Selected

Interface	Status
Interface Status	Not connected

Fig. 15: Web Interface side bar with system state


8.5.2 Gripper state

The gripper state reflects the current state of the gripper and is used to control the process of gripping. It can take the following states.

State	Description
IDLE	The gripper is in its idle state No gripping process is currently in progress
GRASPING	The gripper is closing A part is being gripped, the fingers are moving towards the part. The detection of gripped items is active.
HOLDING	A part is being held A part is being held with the configured force. The monitor of the gripped part has been activated.
PART LOST	A part has been lost The pre-configured gripping force can no longer be applied, presumably because the part to be gripped has been lost.
NO PART FOUND	No part has been found When closing the gripper at the configured position, no part was found to be gripped.
RELEASING	The gripper is opening The gripped part is being released, the fingers are moving.
POSITIONING	Pre-positioning The grippers are being pre-positioned and the fingers are moving.
ERROR	Error An error occurred carrying out the last command. For errors which require acknowledgment, the SF_FAST_STOP flag is also set in the system status word. After any acknowledgment required, the movement can be restarted.

 **The gripper state does not indicate whether the gripper is referenced or not. Instead, the system state flags (SF_REFERENCED) must be read to check this.**

The state of the gripper is shown like the status word in the side bar of the web interface, see Fig.. The diagram Fig. shows the possible transitions between the unit's states.



Stop command: Issuing a Stop command in any state (except ERROR) will abort the current action and immediately return to IDLE state.

Fig. 16: Transitions between the grasping states

8.6 Homing the module

To detect the module's position, it is equipped with a measuring system which can detect the finger's spatial location at a high resolution. Due to the incremental method of position detection, the module has to be homed before motion commands can be executed. The module has a special command for homing which can be issued via the command interface, by a script or via the web interface. It then moves its fingers to the inner or outer physical limit and saves the measured position as a reference value.

To offer maximum flexibility, the module can be referenced to the inner as well as to the outer limit. For outer homing, a factory-calibrated value is used to shift the reference position, so that both variants end up with the same direction and the same origin for the axis coordinates.

⚠ Make sure that the fingers can actually move freely in the reference drive direction up to the module's mechanical limit.

ℹ The homing movement should be carried out in the direction of the required positioning accuracy.

ℹ To automatically execute a homing sequence on start up, activate the "Homing on Start up" option via the web interface ("Settings" → "Motion Configuration")

8.7 Gripping, part detection and grip monitoring

The module is equipped with an integrated detector for parts to be gripped and a grip monitor, which allows reliable handling even for difficult parts without the use of external sensors. To configure these functions, the following parameters are available on the web interface ("Settings" → "Motion Configuration"):

Parameter	Description
Part Width Tolerance	The tolerance of the specified nominal gripper width which is sent to the module with the grasp command. This is measured as the relative gap between two fingers moving towards one another.
Clamping travel	If a part to be gripped has been detected, the module will attempt to apply the required gripping force by moving the fingers within this range. This is measured as the relative gap between two fingers moving towards one another.

Fig. clarifies the function of these two parameters. A grip is only valid (which means it doesn't create an error) if the detected width of the part lies within the hatched area consisting of the part width tolerance and the clamping travel. If no part is detected, then the gripper state will change to "NO PART FOUND". If a contact is detected outside of the defined range, this will be detected as an axis block and the gripper's state will change to "ERROR".

-  **The detector of parts to be gripped and the grip monitor are not running in pre-position mode ("Pre-position" command).**
-  **Damage to the gripper is possible due to insufficient lubrication (dry-running) if the gripper constantly goes through short movements. → every 1000 movements (or at least once per day) the gripper should be moved through its full range of travel.**
-  **For soft parts to be gripped, it may be necessary to increase the clamping travel.**
-  **Setting the part width tolerance to the full range of movement of the module (maximum settings) will deactivate the detection of axis blocking when gripping.**




Fig. 17: Parameters defining a grip

8.8 Software limit switch

The module's travel can be limited via the software limit switch, as shown in Fig.. There is one limit switch for an inner range ("MINUS") and one for an outer range ("PLUS"). If the software limit switches have been activated, then positioning commands to move fingers into this range will get a range error response and the command will not be executed. There is also protection from crossing the edges of these ranges. The monitor will trigger a fast stop which requires acknowledgment if the fingers should be moved into these areas.




Fig. 18: Software limits

The software limits can be set via the command interface, a script or the web interface (“Settings” → “Motion Configuration”).

-  **These software limits do not represent a safety function as understood by the machine directive.**
-  **The software limit switches are always related to the reference position of the base jaws. Bodies on the base jaws or on the gripper jaws are not included!**

-  **If the fingers are within the forbidden area when the software limit switches are activated, then only movements to leave this area will be possible.**

-  **You will find more information on this subject in the "WSG Command Set Reference Manual" and the "WSG Scripting Reference Manual".**

8.9 Fast Stops requiring acknowledgment

The module offers a so-called Fast Stop to put the module into a defined state in case of an error or malfunction. Fast Stops are displayed by setting the SF_FAST_STOP flag in the status word. If a fast stop is triggered, for example due to an insufficient voltage error, then all movement commands will be rejected until

the error is acknowledged and any fault condition has been cleared, with corresponding error codes being returned (access denied).

If the module is in Fast Stop state, power will be removed from the drives but the position reference will be retained.

The error can be acknowledged both via the command interface (the command is: Acknowledging a Fast Stop or fault Condition, 24h) as well as manually by clicking on the "Ack" button in the side bar of the web interface (see Fig.). Fast stops are recorded in the module's event log (see chapter 8.10).

 **Loss of gripping power on fast stop!**

 **The fast stop does not represent a safety function as understood by the machine directive.**

 **A fast stop can also be triggered via the command interface, by a script or manually via the web interface.**

 **For more information, please refer to the "WSG Scripting Reference Manual".**

8.10 Log memory

The module has a non-volatile log memory in which important events are recorded. The events are saved with a timestamp (if no time of day is available via the network, then the time in milliseconds since the system was started will be used) and are displayed in chronological order. If the memory is full, the oldest events will be overwritten. The log memory can be read out via the web interface („Diagnostics“ → „System State“).

8.11 Thermal monitor

To protect the module from overheating, its housing is constantly monitored during operation. The current housing temperature can be checked both via the web interface as well as the command interface.

If the temperature measured exceeds the limit of 65 °C, then a temperature warning will be issued. From a housing temperature of 70 °C the module will change into temperature error mode and will switch the power output stage off via a fast stop. This temperature error must be acknowledged via the "Fast Stop Acknowledge" command.

Temperature warnings and errors are recorded in the module's event log (see chapter 8.10).

 **Loss of gripping force on temperature error!**

 **This error can only be acknowledged if there is no longer a temperature error.**

 The command to read out the current housing temperature and the command to acknowledge the Fast Stop via the command interface are documented in the "WSG Command Set Reference Manual".

8.12 Monitoring the drive current

The drive current is continuously measured and monitored during operation. An integrated motor model is used to check whether the drive is being overloaded or not. In this case, the power output stage will be switched off via a fast stop and a "current fault" will be displayed. The current error must be acknowledged. This can either be done via the web interface or via the command interface using the "Fast Stop Acknowledge" command. Current errors are recorded in the module's event log (see chapter 8.10).

 **Loss of gripping force when there is a current error!**

 This error can only be acknowledged if there is no longer a current error.

 For the documentation of the command to acknowledge the "Fast Stop" via the command interface, see the "WSG Command Set Reference Manual".

8.13 Monitoring the supply voltage

To ensure the correct functioning of the module, the supply voltage to its power section is continuously monitored. If the measured voltage is outside a defined range, a warning or an error will be issued. The following limits apply:

Threshold	Consequence
Supply Voltage ≤ 20 V	Low voltage fault SF_POWER_FAULT will be set in the system's status word and the status indicator will show the error state.
Supply Voltage ≤ 22 V	Low voltage warning SF_POWER_WARNING will be set in the system's status word and the status indicator will show the warning state.
Supply Voltage ≥ 26 V	Excess voltage warning SF_POWER_WARNING will be set in the system's status word and the status indicator will show the warning state.
Supply Voltage ≥ 28 V	Excess voltage error SF_POWER_FAULT will be set in the system's status word and the indicator will show the error state.

Hysteresis is used to prevent the states chattering to and fro. If there is a voltage error, the power output stage will be switched off using a Fast Stop and a voltage error will be indicated. Acknowledging the Fast-

Stop is possible only if the operating voltage is back in its allowed range. Acknowledging can be done either via the web interface or via the command interface by using the "Fast Stop Acknowledge" command.

⚠ Loss of gripper force following an error due to the voltage being too high or too low!

ℹ The low voltage fault will also be triggered if the power supply is interrupted when switching the force off, e.g. via an emergency stop relay.

ℹ This error can only be acknowledged if there is no longer a high/low voltage error.

👉 For the documentation of the system status word and the command to acknowledge the "Fast Stop" via the command interface, see the "WSG Command Set Reference Manual".

8.14 Configuration and diagnosis via the web interface

The module has an integrated web server, with a user interface for configuration and diagnosis. To use this, the module must be connected via Ethernet. To get to the configuration user interface, open a browser and enter the module's IP address (on delivery this is 192.168.1.20) into the browser's address line:




Fig. 19: Entering the IP address to start web-based configuration

The following browsers have been tested and support the module's web interface:

- Mozilla Firefox 16 and above
- Google Chrome 23 and above
- Apple Safari 5 and above
- Mobile Safari (iOS 4.3 and above)
- Internet Explorer 8 and above

ℹ To display the web user interface, JavaScript must be enabled in your browser.




Fig. 20: Web interface for configuration and diagnosis

Via integrated help texts, the module's web interface is intuitive to use. In the upper area you will find a menu bar via which the individual pages can be called up.

8.14.1 Access restrictions for the web user interface

Depending on the network configuration, the module will be visible to everyone in the entire network and the configuration can thus be altered unchecked.

To restrict access to the module's web interface, under "Settings" → "System Configuration" you can activate access restrictions for the interface and create users with differing access rights. If this is activated, each user must be identified with a login name and personal password (see Fig.). Every user is assigned to one of the following user groups:

- **User**
Standard user. Cannot adjust settings, but can only access the pages under the menu options "Diagnostics" and "Help".

- **Administrator**

Administrator. Can adjust all of the module's settings without restriction.



If access restrictions have been activated, then the module will record which user logs in and when.




Fig. 21: Log in window

8.15 Command interface

The module supports control via TCP/IP and UDP/IP. Both interfaces support a text-based communications protocol (Gripper Command Language – GCL), which is described in detail in the document "GCL Reference Manual". Alternatively a binary communications protocol can be used, which is specified in the document "WSG Command Set Reference Manual".

The command interface is selected and configured via the module's web interface, via the menu option "Settings" → "Command Interface".

8.16 Scripting (optional)

If ordered with the option OPT-WSG25-SCR, the modules control unit has an integrated interpreter for the Lua programming language, via which you can adapt the module's software to your application. The programs (scripts) are saved on the integrated non-volatile storage and can be run automatically when the

module starts. The interpreter is configured via the web interface. You will find the reference information for the commands as well as notes about creating and using scripts in the document "WSG Scripting Reference Manual".

8.17 Resetting the configuration

Via the "Settings" → "System" page, the module's configuration can be reset to its state on delivery. Should the configuration interface no longer be accessible, for example if the network configuration is faulty, or if you have forgotten your password, please contact our technical support.

8.18 Implementing the gripping process

In the following section, the steps are described which are needed for a simple handling cycle (preposition - grip - release). The specified commands relate to the command interface. You will find a detailed description of the commands and their parameters in the "WSG Command Set Reference Manual".

Preparatory work:

1. **Adjust the "Clamping Travel" and "Part Width Tolerance" to the application.**
For a description see chapter 8.7.
2. **Perform a test grip.**
You can do this for example via the web interface, menu option "Motion" → "Grasping"

Executing the gripping cycle:

1. **Check whether the gripper has been zeroed (optional)**
If not, run the command "Homing (20h)" and wait until SF_REFERENCED is set in the status word. Request the status word with the command "Get System State (40h)". On error, see section "dealing with errors" below.
2. **Pre-position finger**
Execute the command "Pre-Position Fingers (21h)". Parameters: Opening width and speed. The gripper state changes to "POSITIONING". Wait until the gripper state is "IDLE". Request the gripper state with the command "Get Grasping State (41h)".
3. **Execute the grip**
Command "Grasp Part (25h)". Parameters: Nominal gripping width, gripping speed, gripping force. The gripper state changes to "GRASPING". Wait until the gripper state is "HOLDING". Deal with errors if gripper state is "NO PART FOUND" or "ERROR".
4. **Handling the part**
Periodically request the gripper state and check whether it is still "HOLDING". Deal with errors for "PART LOST" or "ERROR". The periodical requests will not be required if spontaneous messages (see "WSG Command Set Reference Manual") have been activated.

5. Releasing the part

Command "Release Part (26h)". Parameters: Opening width, speed. The gripper state changes to "RELEASING". Wait until the gripper state is "IDLE". Deal with errors on "ERROR".

6. Start again at 2.

Dealing with errors

What to do in case of an error actually depends a lot on the application, but in general requires the user to do something. The following section gives some hints:

1. Does the returned status code differ from E_SUCCESS?

Evaluate the returned status code and eventually request user intervention.

2. Gripper status „ERROR“

request user intervention. Also: Test whether SF_FAST_STOP is set in the status word. If it is, then request acknowledgment.

3. Gripper status „NO PART FOUND“

Depending on the task, jump over the processing and fetch a new part.

4. Gripper status „PART LOST“

Part lost. If necessary, abort processing and fetch new part or request user intervention.



Gripper cycles can also be mapped via a script. For this purpose, please see the "WSG Scripting Reference Manual".



Damage to the gripper is possible due to insufficient lubrication (dry-running) if the gripper constantly goes through short movements. → every 1000 movements (or at least once per day) the gripper should be moved through its full range of travel.

9 Maintenance and cleaning

The maintenance and lubrication intervals must be adapted to the ambient and operating conditions. The following factors should be taken into account here:

- Extreme operating temperatures
- The effects of condensation
- High vibration loading
- Use in a vacuum
- Very dynamic operation
- The effect of foreign substances (e.g. steam, acids, etc.)

Clean the module at regular intervals with a dry cloth to remove all soiling and metal chips. These typically collect in the depressions, on the linear guides for the base jaws and on the edges of the housing.



Damage to the gripper is possible due to insufficient lubrication (dry-running) if the gripper constantly goes through short movements. → every 1000 movements (or at least once per day) the gripper should be moved through its full range of travel.

10 Troubleshooting

10.1 The gripper jaws don't move

Possible cause	Remedy
The base jaws may be jammed in the housing, for example because the surfaces to which they are screwed is not sufficiently flat.	<ul style="list-style-type: none">• Check that the surface is flat where the jaws are to be screwed on• Loosen the module's mounting screws and actuate the module again.
A component is broken, e.g. due to overloading	<ul style="list-style-type: none">• Replace component or send the module with a repair order to Weiss Robotics. Make sure that the module was only used within its defined application parameters.
Operating voltage is not sufficient	<ul style="list-style-type: none">• Check the power supply.• Check the requirements on the power supply.
Communication with the module is not possible	<ul style="list-style-type: none">• Check the connections and communications cables.• Check the interface addressing (e.g. IP address and Port settings).• Check the connection parameters.
Error message in the system (the LEDs on the module illuminate yellow or red)	<ul style="list-style-type: none">• Check the module's operating state.

10.2 Module stops abruptly

Possible cause	Remedy
Power supply interrupted	<ul style="list-style-type: none">• Check the power supply
Communication with the module is not possible	<ul style="list-style-type: none">• Check connections and communication cables.
Fast stop	<ul style="list-style-type: none">• Check the status of the gripper control system.• Determine the cause of the fast stop and remedy if necessary.• Acknowledge the fast stop (see chapter 8.9).
Error message in the system (the operating state indicators of the module illuminate yellow or red)	<ul style="list-style-type: none">• Check the module's operating state.

10.3 No connection to the web interface

Possible cause	Remedy
Power supply interrupted	<ul style="list-style-type: none">• Check the power supply.
Communication with the module is not possible	<ul style="list-style-type: none">• Check the connections and communications cable.• Check the network settings in the module.• Check the network settings in the computer.

11 EC Declaration of Incorporation

In terms of the EC Machinery Directive 2006/42/EG, Annex II, Part B

Manufacturer Weiss Robotics GmbH & Co. KG
 In der Gerste 2
 D-71636 Ludwigsburg

Distributor Weiss Robotics GmbH & Co. KG
 In der Gerste 2
 D-71636 Ludwigsburg

We hereby declare that the following product:

Product designation: Electrical Small Component Gripper WSG 25
Type: WSG 25-064
Part Number: 5010001

Meets the applicable basic requirements of the **Machinery Directive (2006/42/EC)**.

The incomplete machine may not be put into operation until conformity of the machine into which the incomplete machine is to be installed with the provisions of the Machinery Directive (2006/42/EC) is confirmed.

Applied harmonized standards, especially:

EN ISO 12100-1 Safety of machines – Basic concepts, general principles for design – Part 1:
 Basic terminology, methodology

EN ISO 12100-2 Safety of machines – Basic concepts, general principles for design – Part 2:
 Technical principles

The manufacturer agrees to forward on demand the special technical documents for the incomplete machine to state offices.

The special technical documents according to Annex VII, Part B, belonging to the incomplete machine have been created.

Person responsible for documentation: Dr.-Ing. Karsten Weiß, Tel.: +49(0)7141/642062-6

Location, Date/Signature: Ludwigsburg, 17. April 2014



Details of the signatory: Weiss Robotics GmbH & Co. KG



www.weiss-robotics.com

© Weiss Robotics GmbH & Co. KG. All rights reserved.

The technical data mentioned in this document can be changed to improve our products without prior notice. Used trademarks are the property of their respective trademark owners. Our products are not intended for use in life support systems or systems whose failure can lead to personal injury.